

## 1. WALLPAPER STEAMER WARNING .

### **Read and follow Safety Instructions and Cautions on Steamer.**

#### **Read entire Operating Guide before operating this Steamer.**

- This machine produces live steam and/or scalding hot water which could cause severe bodily injury.
- Do not remove the weight cap when the steamer is hot, removal could cause eruption of steam and/or scalding hot water which could result in severe burns or other bodily damage.
- Do not connect or disconnect the hose, steam pan or remove weight cap when steamer is operating. The hose, steam pan and machine fittings are hot and could burn your hands. Unplug the cord and allow steamer to cool down minimum of 10 minutes or more.
- Do not move steamer around when it is operating. If needed to be moved, unplug and allow to cool down minimum of 10 minutes or more.
- The steamer should always be placed on the floor -- never place on any surface that is unstable (such as stairs), or any area that could allow the steamer to tip over.
- When working around switches, outlets or any other electrical devices, be sure the circuit is off by removing the fuse, and turning off the circuit breaker.
- The electrical outlet the steamer is plugged into must be fused and rated for 15 amps or more to prevent blown fused. It's a good idea to unplug other electrical appliances to prevent overloading. If the steamer cord is not equipped with Ground Fault Circuit Interrupter (GFCI), steamer must be plugged into a properly grounded electrical circuit. (110-120 volts USA). If it is necessary to use an extension cord to get to a GFCI outlet, it must be a 3-wire cord with a 3-prong grounding plug. The wire must be no smaller than AWG #14 for up to 50 feet and no smaller than AWG #12 for 50 to 100 feet.
- Do not let the water tank run dry. When refilling ( use a funnel and do not over fill ) -- unplug the electrical cord and allow the steamer to cool down minimum of 10 minutes or more before refilling. Pouring water onto a hot element could cause severe eruptions of steam and/or scalding hot water which could result in severe burns or other bodily damage. Never lay the steam pan across the top of steamer, hot water (condensed steam) could drip into the electrical junction box, which could result in an electrical shock.
- Do not set wallpaper steamer directly on floor or carpet. Always put a drop cloth of canvas or heavy paper, . under the steamer to protect the floor. If there is furniture in the area, cover them also.

#### **SUPPLIES NEEDED**

- Safety Glasses . Gloves, Metal Pail or Pan, Funnel, Scraper 3" to 6", Screwdriver, Drop Cloth, Sponge, Long Pants and Long Sleeve Shirt, and a Wallpaper Perforating tool when used to remove either double layers, painted or vinyl wallpaper.

#### **PREPARATION NECESSARY TO OPERATE STEAMER**

- Use a funnel to fill the steamer with clean water (hot water will heat up faster than cold). Remove weight cap, fill tank until the Water in the water gauge glass is even with the word "FULL" on the water level decal. This is about 1/2", from the top of the glass. Do not overfill. Connect hose to steamer and steam pan, The plug electrical cord into properly grounded outlet, (100-120 USA). While the water is heating, place the steam pan in a metal bucket or cake pan, with the end down that does not have the hose attached to it, to catch any condensation (water) during heat up. It will take about 25 minutes for steamer to produce steam. Allow The steam to come out of the steam pan for a few minutes before starting, then drain the the hot water out of the steam pan into the bucket. Machine runs about 1-1/2 hours on a full tank. When water builds up in steam pan during use, drain into pail to limit steam pan dripping. Do not use any chemicals in water. Always use clean, unsoftened water when available, and a clean pail for filling the water tank. Natural water rarely has enough mineral content to cause trouble, but in some softening processes the water is treated with additional chemicals which cause foaming after a period of time. Dirty water or water with a high mineral content foams up like milk when it is heated. In a

wallpaper steamer, this bubbling water will carry over into the hose and come out through the steam pan. **WALLPAPER REMOVAL** Hold steam pan tight against the wall until coverage is softened, slide the pan one half width and scrape off the loosened paper using a semi-stiff scraper at least 3" wide. If paper does not come off easily, allow more time for the steam to penetrate. If paper has a vinyl coating or painted the seal must be broken to allow the steam to penetrate. Use a perforating tool to break the seal by moving it up and down on the wall. **NOTE:** If walls are going to be painted instead of re wallpaped care needs to be taken when perforating so large holes are not put into the wallboard. Remove paste build up off scraper for easier scraping by wiping blade on remaining wallpaper or use a rag. Continue the above until all paper is removed. It is important to keep the steam pan against the wall at all times when taking off paper. Removing steam pan away from wall wastes steam and job will take longer. Removal of paper can be done by starting at top and sliding the pan downwards . At baseboard and work up from the baseboard back and forth across the wall starting at either top or bottom There is no one way that is quicker than another, as long as you keep sliding the steam pan along, not missing any areas. Side walls should be done first and ceiling last, because the escaping steam helps loosen the ceiling paper. When removing ceiling paper, work with the pan in front of you to prevent hot water from dripping down. Empty the water out of the steam pan into a bucket frequently so it will not build up in pan and drip on you. After paper is removed wipe the wall down with a sponge and clean water to remove any leftover paste. **PAINTED PAPER** Glue base paints permits steam to pass through and do not interfere with steaming off the wallpaper. However, most oil base paints and latex paints prevent the passage of steam. To steam off wallpaper that has been " painted,the paper needs to be perforated to allow steam to penetrate. **WALLBOARD** If the wallboard has been painted with oil base paint or a varnish type sizing (not glue sizing) wallpaper applied over it may be steamed off, just like a plaster wall. If wallboard has not been painted, sealed or sized, removing wallpaper is more difficult. The steam will not damage the unpainted wallboard if you are careful. You will need to experiment with how long to keep the pan in one spot. Use a scraper with well rounded corners to guard against damaging the wallboard. If there is more than one layer of wallpaper on wall, it may be necessary to take off one layer of wallpaper at a time.

#### TROUBLE SHOOTING

Steam not coming out of tool.

- Check that unit has enough water in it.
- Check hose connections. An improperly attached hose will not allow the steam to flow.
- Check for blockage in 15' steam hose caused by condensation. After disconnecting electric power cord, Disconnect hose from steam unit, drain hose as if you were draining a garden hose by holding up 1 end causing water to flow out other end.
- Check that drain holes in steam pan are not blocked or
- Check that weighted tank cap is completely on the tank. If steam escapes out of the seal it will cause a low or no steam condition at the tool.

Red operation light not turning on when plugged in.

- Check GFI unit by pressing the test and then pressing the reset button. If the light still does not turn on check your outlet for voltage. The steamer draws a lot of voltage and can pop the circuit breaker if low voltage or insufficient amp breaker is being used.



